

PICTURE SHOWS COMPONENTS FROM THE INSIDE OF CHASSIS.

REMARK: FORM A SLOPE SO THAT PE-CONNECTION WILL BECOME THE LAST TO STRIP OFF IN

CASE OF PULLING FORCE TO MAINS CABLE:

KEEP POWER WIRES AWAY FROM SIGNAL LINES. DRILL AC WIRES FIRMLY AND GIVE THEM SEPARATE WAY. PUT FILAMENT'S POWER WIRES WELL DRILLED ALONG THE INNER CHASSIS BEND AWAY FROM

SIGNAL WIRES FROM INPUT SOCKETS TO V1 AND FROM V1 TO VOLUME POT SHOULD BE SHIELDED. ALWAYS KEEP WIRES AS SHORT AS POSSIBLE.

Princeton Reverb Amp Clone (AA1146)						
Sheet Physical Layout						
Code BB2008	Document	rinceton_reverb_docs_new.spl7				Rev. A5
Date 01.07.2015		Last edit	17:23:15	Sheet	3	of 3