

Jimmy Page Style Wiring

PUSH/PULL CONTROLS

Bridge volume: splits bridge pickup

Neck volume: splits neck pickup

Bridge tone: puts bridge & neck pickups out of phase with each other

Neck tone: puts bridge & neck pickups in series together

